

solder a wheel collar (b) to it. Make a wire extension, and file a flat (c) on the end to allow it to be properly gripped by the wheel collar's setscrews. When the engine is switched between models, this setup allows the use of extensions of various lengths.

Manuel Torres, Milton, FL